

# Calcium Slayer & Flush

## The Ultimate Press Roller Cleaning Process

Calcium Slayer and Flush obliterates calcium and glaze on rubber rollers and eliminates stripping & hickies that may be caused by glaze. The result is improved ink transfer and ink/water balance. Using Calcium Slayer and Flush will extend roller life and reduces ink consumption. There are no VOCs, no chemical fumes, no hazmat shipping fees, is fully biodegradable and is safe for the user.

When used as prescribed, Calcium Slayer & Flush will remove an abundance of calcium, ink, paper lint and other debris from the ink train rollers. Initial usage may require multiple applications to remove all buildup. Once the press is back to normal operation **use Calcium Slayer & Flush on a weekly basis to maintain optimum roller performance.**

### STEP 1 - Procedures for using Calcium Slayer

- Remove all ink from press rollers.
- Leave ink on the ink fountain roller (ink ball) during usage of both the Calcium slayer and Flush operations.
- Isolate ink train from plate cylinder. Don't drop the forms!
- With press stopped, apply a single 1/4" wide bead of pink Calcium Slayer to the ink roller train. Don't be sloppy!
- Start press and allow to run through ink roller train for 2-3 minutes.
- **Do NOT** rinse Calcium Slayer. Proceed directly to Flush (Step 2) application.

### STEP 2 - Procedures for using Flush

- With press stopped, apply a single 1/4" wide bead of blue Flush to the ink roller train.
- Start press and allow to run through ink roller train for 2-3 minutes.
- Finish with usual press wash procedure.
- You may use hot water for additional rinse if so desired.

For best results read all product directions carefully and adhere to them at all times. Use of protective eyewear is suggested. If eye contact occurs, rinse thoroughly with clean water. May sting on open sores, cuts or around fingernails. Use of nitrile gloves is suggested. Keep out of reach of children. Do not leave on metal surfaces for extended periods of time. If contact with metal occurs, wipe and rinse thoroughly with clean water.

Calcium Slayer & Flush were designed to be used as a two-step roller cleaning system. Do NOT use separately or in reverse order. Follow the prescribed procedures. SAFECID or their authorized agents will not assume any responsibility for improper usage of the products.

For industrial use only

**SAFECID**  
PRINT PRODUCTS

Watertown, WI 800-407-1173

[www.safecid.com](http://www.safecid.com)



MADE IN  
**USA**

